



Commercial
Electric

6M RETRACTABLE CORD REEL

MANUAL – MODEL NO. CERCR6A



2 YEAR
Replacement
Warranty

Please read the operating instructions carefully prior to use. Please retain the instructions in a safe place for future reference.

INTRODUCTION

Congratulations on purchasing a Commercial Electric Retractable Cord Reel. We aim to provide quality tools at an affordable price. We hope you will enjoy using this cord reel for many years.

The Retractable Cord Reel CERCR6A is intended for DIY use only.

SPECIFICATIONS

Model no.:	CERCR6A
Input:	220-240V ~ 50Hz
Amps:	10
Conductor area:	3 x 1.0mm ²
Cord length:	6m
Max. power rating:	2400w
Outer cord diameter:	7mm

SAFETY INSTRUCTIONS

Warning! When using mains-powered equipment, basic safety precautions, including the following, should always be followed to reduce risk of fire, electric shock, personal injury and material damage.

Read the whole manual carefully and make sure you know how to switch the cord reels off, in an emergency, before operating the reel.

Save these instructions and other documents supplied with these reels for future reference.

ELECTRICAL SAFETY

The electric motor has been designed for 230V and 240V only. Always check that the power supply corresponds to the voltage on the rating plate.

Note: The supply of 230V and 240V on cord reels are interchangeable for Australia and New Zealand. If the supply cord is damaged, it must be replaced by the manufacturer or an authorised Service Centre in order to avoid a hazard.

Using an Extension Lead

Always use an approved extension lead suitable for the power input of this reel. Before use, inspect the extension lead for signs of damage, wear and ageing. Replace the extension lead if damaged or defective. When using an extension lead on a reel, always unwind the lead completely. Use of an extension lead not suitable for the power input of the reel or which is damaged or defective may result in a risk of fire and electric shock.

GENERAL SAFETY RULES

Keep work areas clean. Cluttered work areas and benches can cause accidents.

Consider work area environment. Do not expose the cord reel to high humidity or rain. Do not use the cord reel in damp or wet conditions.

Do not abuse the cord. Never carry the reel by its cord. Keep the cord away from heat, oil and sharp edges.

Retract the cord after use.

Have your reel repaired by an authorised electrician. This product complies with relevant safety requirements.

Replacement of the cord. If the cord is damaged, it must be replaced by the manufacturer or an authorised electrician in order to avoid a hazard.

Before use, inspect the extension cord for signs of damage, wear and ageing. If damaged in any way the extension cord must be replaced by the manufacturer or an electrician to avoid risk of fire or electrocution.

OPERATION

WARNING! DO NOT OPERATE WHILE COILED - REMOVE FROM THE CARTON PACKAGING BEFORE USE

Extending and Retracting the Cord

The retractable cord reel is made from high-quality materials and parts, driven and released by a spring which can rewind the cord automatically. It is fitted with a ratchet making it very easy to extend and retract the cord. The cord will extend when pulled. While extending the cord the ratchet will rotate. Every half turn of the reel, you will hear the ratchet, every alternate half turn of the reel you will not hear the ratchet. The cord can be locked at anytime the ratchet is heard. When the cord has been extended to the desired length, allow the reel to slowly retract the cord until it locks. Do not let the cord go until you are sure it has locked.

To retract, extend the cord until the ratchet isn't heard then allow the reels spring to retract the cord. Under no circumstances should the cord be released during this operation. Always hold and walk the cord back to the reel

Reset Button

The reel is designed with internal overload protection, which provides increased protection from electrical fires resulting from a fault in the electrical appliance, circuit wiring or misuse. Should such a fault occur, the internal overload protection will cut off the power supply which prevents the risk of fire, material damage and potentially electrocution. To reset the switch so power is supplied simply press the reset button.

OPERATION (CONT.)

WARNING! If the overload protection is tripped, all devices attached to the unit (including the unit) should be inspected for fault. If the unit trips continuously, then consult an electrician.

Swivel Hanging Ring

This is located on the top of the reel housing. It can be used to mount the reel.

Mounting Accessories

Supplied with the unit is a hook screw. In order to mount the reel using this hook screw, you must first screw the threaded end into a wall or over head beam etc. Once it has been secured you can then hang the reel from it by feeding the swivel hanging ring over the hook. Ensure the surface you are threading the screw into can hold the weight of the reel.

Also supplied with the unit is a bracket and fastening accessories. Alternatively these can be used to hang the reel from. To use these, secure the larger flat side of the bracket to a wall or over head beam etc, using the screws and washers supplied. Then place the reel so the swivel hanging ring is between the brackets two bars. Feed the securing pin supplied through one of the bracket holes into the matching hole in the top of the reel housing, and then through the hole of the other side of the bracket. Ensure the surface you screw the bracket into can hold the weight of the reel.

MAINTENANCE

Cleaning

If the housing of the product requires cleaning do not use solvents but a moist soft cloth only. Never allow any liquid to get inside the product; never immerse any part of the product into liquid.

NOTE: Commercial Electric will not be responsible for any damage or injuries caused by the repair of the product by an unauthorised person or by mishandling or misuse.

CONTENTS

- 1 x Retractable Cord Reel
- 1 x Instruction Manual

PRODUCT WARRANTY

2 YEAR REPLACEMENT WARRANTY

Your Commercial Electric product is covered for a Period of 24 months from the **ORIGINAL**

Date of purchase.

The Warranty covers faulty parts or workmanship.

The warranty is only made available by returning the product to your point of purchase with a **confirmed cash register receipt.**

PURCHASED FROM:

DATE OF PURCHASE:

THIS WARRANTY FORM SHOULD BE RETAINED BY THE CUSTOMER AT ALL TIMES.

WARNING

The following actions will result in the warranty being void:

- If the product has been operated on a supply voltage other than that specified on the unit.
- If the product shows signs of damage or defects caused by or resulting from abuse, accidents or alterations.
- If the product has been disassembled or tampered with in any way.

Note: Warranty excludes consumable parts such as tubes, globes, batteries and all accessories.

YOUR WARRANTY FORM SHOULD BE RETAINED BY YOU AT ALL TIMES.

SHOULD YOU HAVE ANY QUESTIONS PRIOR TO RETURNING YOUR PRODUCT FOR WARRANTY OR REPAIR PLEASE TELEPHONE OUR CUSTOMER SERVICE HELPLINE:

**Australia 1800 069 486
New Zealand 0508 069 486**

TO ENSURE A SPEEDY RESPONSE PLEASE HAVE THE MODEL NUMBER AND DATE OF PURCHASE AVAILABLE. A CUSTOMER SERVICE REPRESENTATIVE WILL TAKE YOUR CALL AND ANSWER ANY QUESTIONS YOU MAY HAVE RELATING TO THE WARRANTY POLICY OR PROCEDURE.

Commercial Electric

5 Chestnut Crt, Dingley, Vic, Australia, 3172

Telephone: 03 9558 3999

Facsimile: 03 9558 0583

www.commercialelectric.com.au